

L4: Ethernet layers

TCP/IP Layer 1


Introduction to Networks v7.0
(ITN)




Ethernet Frames

Ethernet layers

- Ethernet operates in the data link layer and the physical layer.
- It is a family of networking technologies defined in the IEEE 802.2 and 802.3 standards.





Data Link Layer


Introduction to Networks v7.0
(ITN)



Purpose of the Data Link Layer

The Data Link Layer

- The Data Link layer is responsible for communications between end-device network interface cards.
- It allows upper layer protocols to access the physical layer media and encapsulates Layer 3 packets (IPv4 and IPv6) into Layer 2 Frames.
- It also performs error detection and rejects corrupts frames.




IEEE 802 LAN/MAN Data Link Sublayers

IEEE 802 LAN/MAN standards are specific to the type of network (Ethernet, WLAN, WPAN, etc).

The Data Link Layer consists of two sublayers. **Logical Link Control (LLC)** and **Media Access Control (MAC)**.

- The LLC sublayer communicates between the networking software at the upper layers and the device hardware at the lower layers.
- The MAC sublayer is responsible for data encapsulation and media access control.



Purpose of the Data Link Layer

Providing Access to Media

Packets exchanged between nodes may experience numerous data link layers and media transitions.

At each hop along the path, a router performs four basic Layer 2 functions:

- Accepts a frame from the network medium.
- De-encapsulates the frame to expose the encapsulated packet.
- Re-encapsulates the packet into a new frame.
- Forwards the new frame on the medium of the next network segment.

Purpose of the Data Link Layer

Data Link Layer Standards

Data link layer protocols are defined by engineering organizations:

- Institute for Electrical and Electronic Engineers (IEEE).
- International Telecommunications Union (ITU).
- International Organizations for Standardization (ISO).
- American National Standards Institute (ANSI).



Topologies

Physical and Logical Topologies

The topology of a network is the arrangement and relationship of the network devices and the interconnections between them.

There are two types of topologies used when describing networks:

- **Physical topology** – shows physical connections and how devices are interconnected.
- **Logical topology** – identifies the virtual connections between devices using device interfaces and IP addressing schemes.

Topologies

WAN Topologies

There are three common physical WAN topologies:

- **Point-to-point** – the simplest and most common WAN topology. Consists of a permanent link between two endpoints.
- **Hub and spoke** – similar to a star topology where a central site interconnects branch sites through point-to-point links.
- **Mesh** – provides high availability but requires every end system to be connected to every other end system.

Topologies

Point-to-Point WAN Topology

- Physical point-to-point topologies directly connect two nodes.
- The nodes may not share the media with other hosts.
- Because all frames on the media can only travel to or from the two nodes, Point-to-Point WAN protocols can be very simple.



Topologies

LAN Topologies

End devices on LANs are typically interconnected using a star or extended star topology. Star and extended star topologies are easy to install, very scalable and easy to troubleshoot.


Early Ethernet and Legacy Token Ring technologies provide two additional topologies:

- **Bus** – All end systems chained together and terminated on each end.
- **Ring** – Each end system is connected to its respective neighbors to form a ring.


Physical Topologies



Star Topology



Extended Star Topology



Bus Topology



Ring Topology

Topologies

Half and Full Duplex Communication

Half-duplex communication

- Only allows one device to send or receive at a time on a shared medium.
- Used on WLANs and legacy bus topologies with Ethernet hubs.

Full-duplex communication

- Allows both devices to simultaneously transmit and receive on a shared medium.
- Ethernet switches operate in full-duplex mode.

Contention-based access

All nodes operating in half-duplex, competing for use of the medium. Examples are:

- Carrier sense multiple access with collision detection (CSMA/CD) as used on legacy bus-topology Ethernet.
- Carrier sense multiple access with collision avoidance (CSMA/CA) as used on Wireless LANs.

Controlled access

- Deterministic access where each node has its own time on the medium.
- Used on legacy networks such as Token Ring and ARCNET.

Contention-Based Access – CSMA/CD

CSMA/CD

- Used by legacy Ethernet LANs.
- Operates in half-duplex mode where only one device sends or receives at a time.
- Uses a collision detection process to govern when a device can send and what happens if multiple devices send at the same time.

CSMA/CD collision detection process:

- Devices transmitting simultaneously will result in a signal collision on the shared media.
- Devices detect the collision.
- Devices wait a random period of time and retransmit data.

Contention-Based Access – CSMA/CA

CSMA/CA

- Used by IEEE 802.11 WLANs.
- Operates in half-duplex mode where only one device sends or receives at a time.
- Uses a collision avoidance process to govern when a device can send and what happens if multiple devices send at the same time.

CSMA/CA collision avoidance process:

- When transmitting, devices also include the time duration needed for the transmission.
- Other devices on the shared medium receive the time duration information and know how long the medium will be unavailable.

Data Link Frame

The Frame

Data is encapsulated by the data link layer with a header and a trailer to form a frame.

A data link frame has three parts:


- Header
- Data
- Trailer

The fields of the header and trailer vary according to data link layer protocol.

The amount of control information carried with in the frame varies according to access control information and logical topology.

Data Link Frame

Frame Fields





Field	Description
Frame Start and Stop	Identifies beginning and end of frame
Addressing	Indicates source and destination nodes
Type	Identifies encapsulated Layer 3 protocol
Control	Identifies flow control services
Data	Contains the frame payload
Error Detection	Used for determine transmission errors

Data Link Frame

Layer 2 Addresses

- Also referred to as a physical address.
- Contained in the frame header.
- Used only for local delivery of a frame on the link.
- Updated by each device that forwards the frame.





Physical Layer

Introduction to Networks v7.0
(ITN)




The Physical Connection

- Before any network communications can occur, a physical connection to a local network must be established.
- This connection could be wired or wireless, depending on the setup of the network.
- This generally applies whether you are considering a corporate office or a home.
- A Network Interface Card (NIC) connects a device to the network.
- Some devices may have just one NIC, while others may have multiple NICs (Wired and/or Wireless, for example).
- Not all physical connections offer the same level of performance.

Purpose of the Physical Layer

The Physical Layer

- Transports bits across the network media
- Accepts a complete frame from the Data Link Layer and encodes it as a series of signals that are transmitted to the local media
- This is the last step in the encapsulation process.
- The next device in the path to the destination receives the bits and re-encapsulates the frame, then decides what to do with it.



Physical Layer Characteristics

Physical Components

Physical Layer Standards address three functional areas:

- Physical Components
- Encoding
- Signaling


The Physical Components are the hardware devices, media, and other connectors that transmit the signals that represent the bits.

- Hardware components like NICs, interfaces and connectors, cable materials, and cable designs are all specified in standards associated with the physical layer.

Physical Layer Characteristics

Encoding


- Encoding converts the stream of bits into a format recognizable by the next device in the network path.
- This 'coding' provides predictable patterns that can be recognized by the next device.
- Examples of encoding methods include Manchester (shown in the figure), 4B/5B, and 8B/10B.




Physical Layer Characteristics

Signaling


- The signaling method is how the bit values, “1” and “0” are represented on the physical medium.
- The method of signaling will vary based on the type of medium being used.



Electrical Signals Over Copper Cable



Light Pulses Over Fiber-Optic Cable



Microwave Signals Over Wireless

Physical Layer Characteristics

Bandwidth

- Bandwidth is the capacity at which a medium can carry data.
- Digital bandwidth measures the amount of data that can flow from one place to another in a given amount of time; how many bits can be transmitted in a second.
- Physical media properties, current technologies, and the laws of physics play a role in determining available bandwidth.

Unit of Bandwidth	Abbreviation	Equivalence
Bits per second	bps	1 bps = fundamental unit of bandwidth
Kilobits per second	Kbps	1 Kbps = 1,000 bps = 10^3 bps
Megabits per second	Mbps	1 Mbps = 1,000,000 bps = 10^6 bps
Gigabits per second	Gbps	1 Gbps = 1,000,000,000 bps = 10^9 bps
Terabits per second	Tbps	1 Tbps = 1,000,000,000,000 bps = 10^{12} bps

Physical Layer Characteristics

Bandwidth Terminology

Latency

- Amount of time, including delays, for data to travel from one given point to another

Throughput

- The measure of the transfer of bits across the media over a given period of time

Goodput

- The measure of usable data transferred over a given period of time
- $\text{Goodput} = \text{Throughput} - \text{traffic overhead}$

Fiber-Optic Cabling

Fiber-Optic Cabling


Properties of Fiber-Optic Cabling

- Not as common as UTP because of the expense involved
- Ideal for some networking scenarios
- Transmits data over longer distances at higher bandwidth than any other networking media
- Less susceptible to attenuation, and completely immune to EMI/RFI
- Made of flexible, extremely thin strands of very pure glass
- Uses a laser or LED to encode bits as pulses of light
- The fiber-optic cable acts as a wave guide to transmit light between the two ends with minimal signal loss

Fiber-Optic Cabling


Types of Fiber Media

Single-Mode Fiber



- Very small core
- Uses expensive lasers
- Long-distance applications

Multimode Fiber



- Larger core
- Uses less expensive LEDs
- LEDs transmit at different angles
- Up to 10 Gbps over 550 meters

Dispersion refers to the spreading out of a light pulse over time. Increased dispersion means increased loss of signal strength. MMF has greater dispersion than SMF, with a the maximum cable distance for MMF is 550 meters.

Fiber-Optic Cabling

Fiber-Optic Cabling Usage


Fiber-optic cabling is now being used in four types of industry:

1. **Enterprise Networks** - Used for backbone cabling applications and interconnecting infrastructure devices
2. **Fiber-to-the-Home (FTTH)** - Used to provide always-on broadband services to homes and small businesses
3. **Long-Haul Networks** - Used by service providers to connect countries and cities
4. **Submarine Cable Networks** - Used to provide reliable high-speed, high-capacity solutions capable of surviving in harsh undersea environments at up to transoceanic distances.

Our focus in this course is the use of fiber within the enterprise.

Fiber-Optic Cabling

Fiber-Optic Connectors




Straight-Tip (ST) Connectors



Lucent Connector (LC) Simplex Connectors



Subscriber Connector (SC) Connectors



Duplex Multimode LC Connectors

Fiber-Optic Cabling

Fiber Patch Cords



SC-SC MM Patch Cord



LC-LC SM Patch Cord



ST-LC MM Patch Cord



ST-SC SM Patch Cord

A yellow jacket is for single-mode fiber cables and orange (or aqua) for multimode fiber cables.

Fiber-Optic Cabling

Fiber versus Copper

Optical fiber is primarily used as backbone cabling for high-traffic, point-to-point connections between data distribution facilities and for the interconnection of buildings in multi-building campuses.

Implementation Issues	UTP Cabling	Fiber-Optic Cabling
Bandwidth supported	10 Mb/s - 10 Gb/s	10 Mb/s - 100 Gb/s
Distance	Relatively short (1 - 100 meters)	Relatively long (1 - 100,000 meters)
Immunity to EMI and RFI	Low	High (Completely immune)
Immunity to electrical hazards	Low	High (Completely immune)
Media and connector costs	Lowest	Highest
Installation skills required	Lowest	Highest
Safety precautions	Lowest	Highest

Wireless Media

Properties of Wireless Media

It carries electromagnetic signals representing binary digits using radio or microwave frequencies. This provides the greatest mobility option. Wireless connection numbers continue to increase.

Some of the limitations of wireless:

- **Coverage area** - Effective coverage can be significantly impacted by the physical characteristics of the deployment location.
- **Interference** - Wireless is susceptible to interference and can be disrupted by many common devices.
- **Security** - Wireless communication coverage requires no access to a physical strand of media, so anyone can gain access to the transmission.
- **Shared medium** - WLANs operate in half-duplex, which means only one device can send or receive at a time. Many users accessing the WLAN simultaneously results in reduced bandwidth for each user.

Types of Wireless Media

The IEEE and telecommunications industry standards for wireless data communications cover both the data link and physical layers. In each of these standards, physical layer specifications dictate:

- Data to radio signal encoding methods
- Frequency and power of transmission
- Signal reception and decoding requirements
- Antenna design and construction

Wireless Standards:

- **Wi-Fi (IEEE 802.11)** - Wireless LAN (WLAN) technology
- **Bluetooth (IEEE 802.15)** - Wireless Personal Area network (WPAN) standard
- **WiMAX (IEEE 802.16)** - Uses a point-to-multipoint topology to provide broadband wireless access
- **Zigbee (IEEE 802.15.4)** - Low data-rate, low power-consumption communications, primarily for Internet of Things (IoT) applications

In general, a Wireless LAN (WLAN) requires the following devices:

- **Wireless Access Point (AP)** - Concentrate wireless signals from users and connect to the existing copper-based network infrastructure
- **Wireless NIC Adapters** - Provide wireless communications capability to network hosts

There are a number of WLAN standards. When purchasing WLAN equipment, ensure compatibility, and interoperability.

Network Administrators must develop and apply stringent security policies and processes to protect WLANs from unauthorized access and damage.